ZANUSSI

FREEZER

ZFE 74 W

INSTRUCTION BOOKLET

2222691-69

CONTENTS

Instructions for the User

Important Safety Instructions 3

Description of the Appliance 4

Operation 5

Before use 5
Starting your appliance 5
Temperature control 5
Warning light (red) 5
Temperature acoustic alarm 5
Freezing fresh food 6
Frozen food storage 6
Freezing calendar 6
Cold accumulator 6
Thawing 7
Ice making 7
Normal Operating Sound 7

Health and Safety Guidelines 7

Defrosting 8

Maintenance and Cleaning 9

Internal cleaning 9
External cleaning 9
When the appliance is not in use 9

Something Not Working? 10

Service and Spare Parts 11

Customer Care Department 11

Guarantee Conditions 12

Service Force Addresses 13

Instructions for the Installer

Technical Specifications 15

Installation 15

Positioning 15
Door reversal 16

Electrical Connection 17

⚠ IMPORTANT SAFETY INSTRUCTIONS

These warnings are provided in the interests of your safety. Ensure that you understand them all before installing or using this appliance. Your safety is of paramount importance. If you are unsure about any of the meanings of these warnings contact the Customer Care Department.

Prior to Installation

- Check the appliance for transport damage. Under no circumstance should a damaged appliance be installed. In the event of damage please contact your retailer.

Installation

- This appliance is heavy. Care should be taken when moving it.
- It is dangerous to alter the specifications or attempt to modify this product in any way.
- Ensure that the appliance does not stand on the electrical supply cable.
  Important: if the supply cable is damaged, it must be replaced by a cable available from the manufacturer or your local Service Force Centre.
- Any electrical work required to install this appliance should be carried out by a qualified electrician or competent person.
- Parts which heat up should not be exposed. Whenever possible, the back of the appliance should be close to a wall, but leaving the required distance for ventilation, as stated in the installation instructions.
- The appliance should be left for 2 hours after installation before it is turned on, in order to allow the refrigerant to settle.

Refrigerant

- The refrigerant isobutane (R600a) is contained within the refrigerant circuit of the appliance, a natural gas with a high level of environmental compatibility, which is nevertheless flammable.
- During transportation and installation of the appliance, be certain that none of the components of the refrigerant circuit become damaged.
- If the refrigerant circuit should become damaged:
  - avoid open flames and sources of ignition.
  - thoroughly ventilate the room in which the appliance is situated.

Child Safety

- Do not allow children to tamper with the controls or play with the product.
- There is a risk of suffocation! Keep packaging material away from children!

General Safety

- **This appliance contains hydrocarbons in its cooling unit; maintenance and recharging must therefore only be carried out by authorised technicians.**
- **Take utmost care when handling your appliance so as not to cause any damages to the cooling unit with consequent possible fluid leakages.**
- **The appliance must not be located close to radiators or boilers.**
- **Avoid prolonged exposure of the appliance to direct sunlight.**
- **Do not use other electrical appliances (such as ice cream makers) inside of refrigerating appliances.**

During Use

- This appliance is designed for domestic use only, specifically for the storage of edible foodstuffs. It is not intended for commercial or industrial use.
- Containers with flammable gases or liquids can leak at low temperatures. Do not store any containers with flammable materials, such as spray cans, fire extinguisher refill cartridges etc. in the freezer.
- Frozen food should not be refrozen once it has thawed out.
- Do not place carbonated or fizzy drinks in the freezer compartment.
- Ice lollies can cause ‘frost/freezer burns’ if consumed straight from the freezer.
- Do not remove items from the freezer compartment if your hands are damp/wet, as this could cause skin abrasions or frost/freezer burns.
- Placing frozen goods on the top of the appliance can lead to the accumulation of condensation in the cavity of the storage tray through contact with the cold. Electronic components are housed within this cavity. If condensation should drip onto these components, the appliance could be damaged by a short circuit. For this reason do not place frozen goods on top of the appliance.
- Bottles and cans must not be placed in the freezer as they can burst when the contents freeze.

- Manufacturers' recommended storage times should be adhered to. Refer to relevant instructions.

Maintenance and Cleaning

- Before cleaning, always switch off the appliance and disconnect from the electrical supply.
- When unplugging always pull the plug from the mains socket, do not pull on the cable.

Servicing

- This product should be serviced by an authorised engineer and only genuine spare parts should be used.
- Under no circumstances should you attempt to repair the appliance yourself. Repairs carried out by inexperienced persons may cause injury or serious malfunctioning. Contact your local Service Force Centre.

At the end of the Appliance Life

- When disposing of your appliance use an authorised disposal site.
- Remove the plug and ensure that any locks or catches are removed, to prevent young children being trapped inside.

DESCRIPTION OF THE APPLIANCE

① Freezer controls

② Compartment for frozen food storage

③ Compartment for freezing fresh food



OPERATION

Before use

Remove all securing tapes. Wash inside the appliance with lukewarm water and bicarbonate of soda (5 ml to 0.5 litre of water). Do not use soap or detergent as the smell may linger. Dry thoroughly.

Freezer controls



① Pilot light (green)

② Thermostat control knob

③ Fast-freezing indicator light (yellow)

④ Push button for fast-freezing

⑤ Warning light (red)

Starting your appliance

Insert the plug into the wall socket. The appliance can be activated by turning the thermostat knob ② beyond the “-16°C” position. When the pilot light ① is illuminated this shows that the appliance is on. Freezer operation can be halted by turning knob ② to position «●».

Temperature control

The temperature inside the freezer is regulated by a thermostat with 5 temperature positions and one «OFF» (●) position.

Position «-16°C» = minimum cold

Position «-24°C» = maximum cold

Turn the thermostat dial to the required position.

An intermediate position (-18°C) is usually the most suitable, although the temperature will be affected by:

- Room temperature
- How often the door is opened
- How much food is stored
- Position of the appliance

In determining the correct temperature control setting all these factors have to be considered and some experimentation may be necessary.

To obtain a lower temperature, turn the thermostat control to the higher numbers; to obtain a higher temperature turn the control to the lower numbers. When altering the temperature setting, allow 24 hours for the temperature to stablise before making further changes.

Warning light (red)

If the temperature warning light ⑤ lights up, it indicates that the temperature within the freezer has reached a level where safe food storage is no longer ensured (warmer than -12°C).

When the freezer is first switched on, the warning light will stay on until the temperature has dropped to a safe level for the storage of frozen food.

Freezing fresh food

In any 24 hour period you can freeze up to 20 kg of fresh food.
Activate fast freeze by depressing the fast-freeze button ④ - for more than one second - 24 hours before you want to freeze your fresh food, the yellow light ③ illuminates. This time can be shortened, depending on the quantity of food to be frozen.
After the time has elapsed place the food to be frozen in the appliance's two top compartments; if freezing only a small amount of food, use the top compartment.
In the top compartment, products must only be stacked up to the mark on the cabinet wall so as to ensure that air circulation is not obstructed.

You should never freeze more than 20 Kg. of fresh food at anyone time.

Once the food is completely frozen (which could take up to 24 hours) the fast freeze function can be ended manually by depressing the switch ④ again. The yellow light goes out. If the fast freeze function is not ended manually, the appliance electronics switch off the fast freeze function after 48 hours. The yellow light ③ goes out.

Distribute the frozen food packages in the other compartments, so that the two top compartments can be used for a further freezing operation. Only freeze top quality, fresh and thoroughly cleaned foodstuffs.
Do not allow fresh food to touch food which is already frozen.
During the freezing process, ensure that the freezer door remains closed.

Frozen food storage

When you first start the freezer or if the freezer has been out of use for some time, we advise you to run your appliance for at least two hours in the «fast freeze» mode before storing frozen food.

To obtain the best performance from this appliance, we strongly recommend that you make sure that the commercially frozen foodstuffs were adequately stored by the retailer and, furthermore, be sure that these frozen foodstuffs are transferred from the foodstore to the consumer in the shortest possible time (a temperature increase of the frozen food could shorten its storage period).

It is also advisable not to exceed the storage period indicated by the producer of the food.

Finally, do not open the door frequently or leave it open longer than is absolutely necessary.

Important

Do not put carbonated liquids, (fizzy drinks etc.), in the freezer compartment.

Ice lollies, if consumed immediately after removal from the freezer, can possibly result in a low temperature skin burn.

Do not remove items from the freezer if your hands are damp/wet, as this could cause skin abrasions or "frost/freezer burns".

If there is a power failure during the storage of frozen food, do not open the door during the whole time of the power failure. If the freezer is fully loaded, the frozen food will not be affected if the power cut is of short duration; otherwise, it is recommended to consume the food within a very short time.

To remove the drawers, proceed as follows: pull the drawer out until it comes to a stop, then tilt it upwards (see figure).



Freezing calendar

The symbols on the drawers show different types of frozen goods.
The numbers indicate storage times in months for the appropriate types of frozen goods. Whether the upper or lower value of the indicated storage time is valid depends on the quality of the foods and pre-treating before freezing.

Cold accumulator

The freezer contains one cold accumulator which can be found in the top compartment. The cold accumulator increases storage times in the event of a power cut or breakdown. It must be placed on top of the food.
Removal of this unit will increase the capacity of the fast freezing compartment but will reduce storage times in the event of a power cut or breakdown.

Thawing

Frozen food, prior to being used, can be thawed in the fridge or at room temperature depending on the time available. Small food items may even be cooked from frozen; in this case cooking will take longer. Any frozen food which is allowed to thaw accidentally should either be eaten as soon as possible or thrown away. Alternatively, if the food is uncooked and has not been completely defrosted it can be cooked and then refrozen.

Defrosted cooked food must never be refrozen.

Ice making

Fill each compartment of the ice tray 3/4full with water and place it in the freezer. To release the ice cubes, twist the tray along its length. Never use a sharp instrument to remove ice from the tray.

Normal Operating Sounds

You may hear faint gurgling or bubbling sounds when the refrigerant is pumped through the coils or tubing at the rear, to the fixed freezer shelves.

When the compressor is on, the refrigerant is being pumped round, and you will hear a whirring sound or pulsating noise from the compressor.

A thermostat controls the compressor, and you will hear a faint ‘click’ when the thermostat cuts in and out.

HEALTH AND SAFETY GUIDELINES

Because of consumer demand, preservatives have been removed from many pre-prepared foods. This together with the changes in shopping habits to a once-a-week shop, mean that safe handling and storage of food is even more important than ever.
The following tips should help you to ensure that the food in your home is in as perfect condition as possible.

- Keep the freezer door closed as much as possible.
- Do not push food together too much, try to allow air to circulate around each item.
- Cool cooked food as quickly as possible but do NOT place in the freezer until cool. (Leave food in a place as cool as possible in order that it can then be placed in the refrigerator as soon as possible).
- Do not store food uncovered.
- The best way to defrost food is to put it in the refrigerator to thaw slowly.
- Ensure that food placed in the freezer is dated and labelled and used in date order to ensure that food is consumed at its best.
- It is important that food is used before its “best before” date.
- Always wash your hands with soapy water and dry them with a clean towel before handling food.
- Keep work surfaces clean and avoid cross contamination by not using the same work surface or knife, without washing them thoroughly in between.
- The foods to be frozen must be fresh and of the best quality.
- The size of each pack should be small enough to ensure that it is used in one go. Small packs freeze more quickly and uniformly and give better results.
- Frozen food, once thawed, must not be refrozen. Lean food keeps better and longer than fatty food, salt reduces the storage time.
- Wrap the food in polythene or aluminium freezing bags or foil so that they adhere to the food and provide an airtight seal.
- Packaging which is swollen or has traces of refrozen water droplets on the pack could indicate that the product has not been kept at a suitable temperature and that it may have lost its original quality. Partially thawed food must not be refrozen, it must be consumed within 24 hours. Never exceed the storage time indicated.
- Never place hot food, bottles or cans of fizzy drink in the freezer as they may explode. Containers with a lid must not be filled to the brim.
- Do not open the door or place extra fresh food in the freezer next to food which is already frozen as this could cause the temperature of the frozen food to rise and its quality and storage life to reduce.

DEFROSTING

The freezer compartment will become progressively covered with frost. This should be removed with the special plastic scraper provided, whenever the thickness of the frost exceeds 1/4".

During this operation it is not necessary to switch off the power supply or to remove the foodstuffs. However, when the ice becomes very thick on the inner liner, complete defrosting should be carried out and it is advisable to carry out this operation when the appliance is empty.

To carry out complete defrosting proceed as follows:

1. Remove any stored food, wrap it in several layers of newspaper and put it in a cool place.
2. Turn the thermostat control knob ② to the «●» setting.
3. Leave the door open and insert the plastic scraper in the special location to act as an extension channel; pull out the drawer to collect the defrost water (see Fig.).
4. When defrosting is completed, dry the interior thoroughly.



Keep the scraper for future use.

Turn the thermostat control knob to a medium setting (-18°C) and, after letting the appliance run for at least two hours in the «fast freeze» mode, replace the previously removed food into the compartments.

Important

A temperature rise of the frozen food packs during defrosting may shorten their storage life.

Never use sharp metal tools to scrape off frost from the evaporator as you could damage the appliance beyond repair.

Important

In the event of a power failure causing the temperature within your freezer to rise, do not re-freeze the food without checking its condition. The following guidelines should assist you:

Ice-cream: once thawed should be discarded.
Fruits & Vegetables: if soft should be cooked and used up.
Breads & Cakes: can be re-frozen without danger.
Shellfish: should be refrigerated and used up quickly.
Cooked Dishes: i.e. casseroles should be refrigerated and used up.
Large Pieces of Meat: can be re-frozen providing there are still ice crystals remaining within them.
Small Joints: should be cooked and can then be re-frozen as cooked dishes.
Chicken: should also be cooked and re-frozen as a cooked dish.

MAINTENANCE AND CLEANING

Before any maintenance or cleaning work is carried out, DISCONNECT the appliance from the ELECTRICITY supply.

Warning
This appliance contains hydrocarbons in its cooling unit maintenance and recharging must therefore only be carried out by authorised technicians.

Internal cleaning

Clean the inside and accessories with warm water and bicarbonate of soda (5ml to 0.5 litre of water). Rinse and dry thoroughly.
NEVER USE DETERGENTS, ABRASIVE POWDERS, HIGHLY PERFUMED CLEANING PRODUCTS OR WAX POLISHES, TO CLEAN THE INTERIOR AS THESE WILL DAMAGE THE SURFACE AND LEAVE A STRONG SMELL.

Important
Do not use abrasive products.

External cleaning

Wash the outer cabinet door with warm soapy water. Do NOT use abrasive products.
Once or twice a year dust the condenser (black grill) and the compressor at the back of the appliance, with a brush or vacuum cleaner, see figure.
You MUST ensure that the appliance is switched OFF. An accumulation of dust will affect the performance of the appliance and cause excessive electricity consumption.



When the appliance is not in use

When the appliance is not in use for long periods, disconnect from the electricity supply, empty all foods and clean the appliance, leaving the door ajar to prevent unpleasant smells.

SOMETHING NOT WORKING?

Before contacting your local Service Force Centre check the following points.

IMPORTANT: If you call out an engineer to a fault listed below, or to repair a fault caused by incorrect use or installation, a charge will be made even if the appliance is under guarantee.

Symptom	Solution
No power to appliance	- Check there is power at the socket. - Check there is not a power cut by checking the household lights. - Check the fuse has not blown.
The temperature in the freezer is too high	- Check the thermostat control knob is turned to the correct setting relative to ambient conditions. - Check the ambient temperature is within the appliances operating limits of 10°C to 32°C. - Relocate the appliance if necessary.
The freezer door will not open	- Has door just been opened? If so leave for a few minutes to allow the air pressure to equalise.
The compressor runs continuously	- Adjust the thermostat control knob to give correct temperature control. See page 5. - Check that the door is closed. - Large quantities of food have recently been placed in the cabinet and/or door is frequently opened. - Check that air ventilation is not obstructed.
Excessive frost and ice has built up.	- Ensure the door is not left open. - Check that nothing is preventing the door from closing. - Is the door gasket intact and clean? - Has advised periodic defrosting been carried out?
Noise	- Refer to normal operating sounds.

If after the above checks, there is still a fault, call your local Service Force Centre.

In-guarantee customers should ensure that the above checks have been made as the engineer will make a charge if the fault is not a mechanical or electrical breakdown.

Please note that proof of purchase is required for any in-guarantee service calls.

Malfunctions

If the electronics in the appliance have detected a fault that prevents the ACTUAL temperature being measured, the warning light in the temperature display will flash. The appliance will continue to function using a backup program until your local Service Force Engineer has repaired the appliance.

SERVICE AND SPARE PARTS

In the event of your appliance requiring service, or if you wish to purchase spare parts, please contact your local Zanussi Service Force Centre by telephoning:-

08705 929929

Your telephone call will be automatically routed to the Service Force Centre covering your post code area. The addresses are listed on the following pages.

Before calling out an engineer, please ensure you have read the details under the heading 'Something Not Working'.

When you contact the Service Centre you will need to give the following details.

1. Your name, address and post code
2. Your telephone number
3. Clear and concise details of the fault
4. The model serial no. of the appliance (found on the rating plate)
5. The purchase date

CUSTOMER CARE DEPARTMENT

For general enquiries concerning your Zanussi appliance or for further information on Zanussi products, you are invited to contact our Customer Care Department by letter or telephone or visit our website at www.zanussi.co.uk

Customer Care Department
Zanussi
55-77 High Street
Slough
Berkshire
SL1 1DZ

Tel: 08705 727727 **(*)**

(*) calls to this number may be recorded for training purposes.

SERVICE FORCE

To contact your local Service Force Centre telephone 08705 929 929

CHANNEL ISLANDS

GUERNSEY	**Guernsey Electricity PO Box 4 Vale, Guernsey Channel Islands GY1 3AD**
JERSEY	**Jersey Electricity Company Haut De L'orme Rue De Haut De L'orme Trinity Jersey Channel Islands JE3 5FG**

SCOTLAND

ABERDEEN	**54 Claremont Street Aberdeen AB10 6RA**
AUCHTERMUCHTY	**33a Burnside Auchtermuchty Fife KY14 7AJ**
BLANTYRE	**Unit 5 Block 2 Auchenraith Ind. Estate Rosendale Way Blantyre G72 0NJ**
DUMFRIES	**93 Irish Street Dumfries DG1 2 PQ**
DUNOON	**7 Hill Street Dunoon Argyll PA23 7AL**
EDINBURGH	**Unit 12 Dumbryden Ind. Estate 2 Dumbryden Road Edinburgh EH14 2AB**
GLASGOW	**Unit 4 Wellington Road Bishopriggs Glasgow G64 2SA**
INVERNESS	**Unit 3BI Smithton Ind. Estate Smithton Inverness IV2 7WL**
ISLE OF ARRAN	**R Haggerty Bruach Blackwaterfoot Isle of Arran**
ISLE OF BARRA	**J Zerfah 244 Bruernish Isle of Barra Western Islands HS9 5QY**
ISLES OF BUTE	**Walker Engineering Glenmhor Upper Serpentine Road Rothesay Isle of Bute PA20 9EH**
ISLE OF LEWIS	**ND Macleod 16 James Street Stornoway Isle of Lewis PA87 2QW**
KELSO	**2, 6 & 8 Woodmarket Kelso Borders TD5 7AX**
ORKNEY	**7 King Street Kirkwall Orkney KW15 1JF**
PERTH (OWN SALES)	**Scottish Hydro Electric Central Warehouse Inveralmond Perth PH1 3AF**
SHETLAND (OWN SALES)	**3-4 Carlton Place Lerwick Shetland ZE1 0PW**
SHETLAND (OWN SALES)	**Bolts Shetland 26 North Road Lerwick Shetland ZE1 0PE**
WHALSAY (OWN SALES)	**Leask Electrical Harisdale Symbister, Whalsay Shetland ZE2 9AA**

NORTHERN IRELAND

BELFAST	**Owenmore House Kilwee Business Park Dunmurry Belfast BT17 0HD**

WALES

CARDIFF	**Unit 4 Guardian Industrial Estate Clydesmuir Road Cardiff CF2 2QS**
CLYWD	**Unit 6-7 Coed Parc Abergele Road Rhuddlan Clwyd LL18 5UG**
DYFED	**Unit 9 St. Clears Business Park Tenby Road St. Clears Carmarthen SA33 4JW**
OSWESTRY	**Plas Ffynnon Warehouse Middleton Road Oswestry SY11 2PP**

NORTH EAST

GATESHEAD	**Unit 356a Dukesway Court Dukesway Gateshead NE11 0BH**
GRIMSBY	**15 Hainton Avenue Grimsby N. E. Lincs DN32 9AS**
HULL	**Unit 1 Boulevard Industrial Estate Hull HU3 4AY**
LEEDS	**64-66 Cross Gates Road Cross Gates Leeds LS15 7YS**
NEWTON AYCLIFFE	**Unit 23 Northfield Way Aycliffe Industrial Park Newton Aycliffe DL5 6EJ**
SHEFFIELD	**Pennine House Roman Ridge Road Sheffield S9 1GB**

NORTH WEST

BIRKENHEAD	**1 Kelvin Park Dock Road Birkenhead CH41 1LT**
CARLISLE	**Unit 7 James Street Workshops James Street Carlisle Cumbria CA2 5AH**
ISLE OF MAN	**South Quay Ind. Estate Douglas Isle of Man IM1 5AT**
BOLTON	**Unit B Central Industrial Estate St Marks Street Bolton BL3 6NR**
PRESTON	**Unit 250 Dawson Place Bamber Bridge Preston Lancashire PR5 8AL**
STOCKPORT	**Unit 20 Haigh Park Haigh Avenue Stockport SK4 1QR**

SERVICE FORCE

To contact your local Service Force Centre telephone 08705 929 929

MIDLANDS

BIRMINGHAM	**66 Birch Road East Wyrley Trading Estate Witton Birmingham B6 7DB**
BOURNE	**Pinfold Road Bourne PE10 9HT**
BRIDGNORTH	**68 St. Mary's Street Bridgnorth Shropshire WV16 4DR**
GLOUCESTER	**101 Rycroft Street Gloucester GL1 4NB**
HEREFORD	**Units 3 & 4 Bank Buildings Cattle market Hereford HE4 9HX**
HIGHAM FERRERS	**30 High Street Higham Ferrers Northants NN10 8PL**
ILKESTON	**Unit 2 Furnace Road Ilkeston DE7 5EP**
LEICESTER	**Unit 7 Oaks Industrial Estate Coventry Road Narborough Leicestershire LE9 5GF**
LINCOLN	**Unit 8 Clifton Street Stone Field Park Lincoln LN5 8LQ**
NEWCASTLE UNDER LYME	**18-21 Croft Road Brampton Ind. Estate Newcastle under Lyme Staffordshire ST5 0TW**
REDDITCH	**13 Thornhill Road North Moons Moat Redditch Worcestershire B98 9ND**
TAMWORTH	**Unit 3 Sterling Park Claymore Tamworth B77 5DQ**
WORCESTER	**Units 1 & 2 Northbrooks Close Gregorys Mill Ind. Estate Worcester WR3 8BP**

LONDON & EAST ANGLIA

BECKENHAM	**11a Gardner Ind. Estate Kent House Lane Beckenham Kent BR3 1QZ**
CHELMSFORD	**Hanbury Road Widford Ind. Estate Chelmsford Essex CM12 3AE**
COLINDALE	**Unit 14 Capitol Park Capitol Way Colindale London NW9 0EQ**
ELTHAM	**194 Court Road Mottingham Eltham London SE9 4EW**
ENFIELD	**284 Alma Road Enfield London EN3 7BB**
GRAVESEND	**Unit B4 Imperial Business Estate West Mill Gravesend Kent DA11 0DL**
IPSWICH	**Unit 6C Elton Park Business Centre Hadleigh Road Ipswich IP2 0DD**
LETCHWORTH	**16-17 Woodside Ind. Park Works Road Letchworth Herts SG6 1LA**
LONDON	**2 - 4 Royal Lane Yiewsley West Drayton Middlesex UB7 8DL**
MAIDENHEAD	**Reform Road Maidenhead Berkshire SL6 8BY**
MOLESEY	**10 Island Farm Avenue West Molesey Surrey KT8 2UZ**
NEWBURY	**9 Pipers Court Berkshire Drive Thatcham Berkshire RG19 4ER**
NORWICH	**2b Trafalgar Street Norwich NR1 3HN**
SUNBURY	**Unit 1a The Summit Hanworth Road Sunbury on Thames TW16 5DB**

SOUTH EAST

ASHFORD	**Unit 2 Bridge Road Business Centre Bridge Road Ashford Kent TN23 1BB**
FLEET	**Unit 1 Redfields Ind. Estate Church Crookham Fleet Hampshire GU13 0RD**
HAYWARDS HEATH	**21-25 Bridge Road Haywards Heath Sussex RH16 1UA**
TONBRIDGE	**Unit 30 Deacon Trading Estate Morley Road Tonbridge TN9 1RA**

SOUTH WEST

BARNSTAPLE	**Main Road Fremington Barnstaple North Devon EX31 2NT**
BOURNEMOUTH	**63-65 Curzon Road Bournemouth Dorset BH1 4PW**
BRIDGEWATER	**6 Herswell Business Park Salmon Parade Bridgwater Somerset TA6 5PY**
BRISTOL	**11 Eldon Way Eldonwall Trading Estate Bristol BS4 3QQ**
EMSWORTH	**266 Main Road Southbourne Emsworth PO10 8JL**
ISLE OF WIGHT	**Unit 8 Enterprise Court Ryde Business Park Ryde Isle of Wight PO33 1DB**
NEWTON ABBOT	**Unit 2 Zealley Ind. Estate Kingsteignton Newton Abbot TQ12 3TD**
REDRUTH	**Unit 7D Pool Ind. Estate Druids Road Redruth Cornwall TR15 3RH**

GUARANTEE CONDITIONS

Standard guarantee conditions

We, Zanussi, undertake that if within 12 months of the date of purchase this Zanussi appliance or any part thereof is proved to be defective by reason only of faulty workmanship or materials, we will, at our option repair or replace the same FREE OF CHARGE for labour, materials or carriage on condition that:

- The appliance has been correctly installed and used only on the electricity supply stated on the rating plate.
- The appliance has been used for normal domestic purposes only, and in accordance with the manufacturer's instructions.
- The appliance has not been serviced, maintained repaired, taken apart or tampered with by any person not authorised by us.
- All service work under this guarantee must be undertaken by a Zanussi Service Force Centre.
- Any appliance or defective part replaced shall become the Company's property.
- This guarantee is in addition to your statutory and other legal rights.

Home visits are made between **8.30am** and **5.30pm** Monday to Friday. Visits may be available outside these hours in which case a **premium** will be charged.

Exclusions

This guarantee does not cover:

- Damage or calls resulting from transportation, improper use or neglect, the replacement of any light bulbs or removable parts of glass or plastic.
- Costs incurred for calls to put right an appliance which is improperly installed or calls to appliances outside the United Kingdom.
- Appliances found to be in use within a commercial environment, plus those which are subject to rental agreements.
- Products of Zanussi manufacture which are not marketed by Zanussi.

European Guarantee

If you should move to another country within Europe then your guarantee moves with you to your new home subject to the following qualifications:

- The guarantee starts from the date you first purchased your product.
- The guarantee is for the same period and to the same extent for labour and parts as exists in the new country of use for this brand or range of products.
- This guarantee relates to you and cannot be transferred to another user.
- Your new home is within European Community (EC) or European Free Trade Area.
- The product is installed and used in accordance with our instructions and is only used domestically, i.e. a normal household.
- The product is installed taking into account regulations in your new country.

Before you move please contact your nearest Customer Care centre, listed below, to give them details of your new home. They will then ensure that the local Service Organisation is aware of your move and able to look after you and your appliance.

France	Senlis	+33 (0) 44 62 29 99
Germany	Nurenberg	+49 (0) 911 323 2600
Italy	Pordenone	+39 (0) 1678 47053
Sweden	Stockholm	+46 (0) 8 738 79 50
UK	Slough	+44 (0) 1753 219897

TECHNICAL SPECIFICATIONS

DIMENSIONS	Height	85	cm
	Width	59.5	cm
	Depth	60	cm
POWER SUPPLY VOLTAGE AND FREQUENCY	220-240 V / 50 Hz		
TOTAL POWER ABSORBED	90 W		
AVERAGE DAILY UNITS ELECTRICITY(*)	0,56 kWh		
GROSS CAPACITY	110 l		
NET CAPACITY	96 l		
STAR RATING	****		

(*)This figure is based on standard test results in accordance with European Standard EN153 (Actual consumption will depend on how the appliance is used and where it is located).

INSTALLATION

Positioning

For this appliance to work efficiently, it must not be located where the temperatures will fall below 10°C (50°F) or rise above 32°C (90°F), e.g. conservatories.

For correct operation this appliance must be located in a dry atmosphere, away from heat sources, e.g. cookers, radiators, boilers and direct sunlight.

You should also ensure that air can circulate freely around the back and the top of the cabinet. There should be 100mm (4”) between the top of the cabinet and any overhanging kitchen furniture. Alternatively allow 50mm (2”) between the top of the cabinet and any overhanging kitchen furniture and a gap of 25mm (1”) on either side of the appliance.

Do not obstruct the space underneath. The back of the cabinet may be placed close to the wall but must not touch it. DO NOT install in places with restricted ventilation.

Adjust the level of the appliance by screwing out the adjustable foot, or feet, at the bottom of the cabinet using your fingers.





Door reversal

Before carrying out the operations described below, pull out the mains plug from the wall socket.
To carry out this reversal go through the following steps:

1. Gently lay the appliance on its back with the top held away from the floor by 5-8 cm (2-3 inches) of packing.

2. Remove the bottom door hinge (5).

3. Remove the door (4) by opening it and pulling it gently downwards to remove it from the top hinge pin (2).

4. Unscrew the top hinge pin (2) from the top hinge (1) and replace it in the opposite hole on the left hand side.

5. Unscrew the foot at the base (6) of the appliance and refit it on the opposite side.

6. Refit the door and the bottom hinge to the left hand side.



When positioning the bottom hinge blade on the reverse side, the securing screws will require a degree of exersion when fitting.
It is therefore advisable to lubricate the screw tips before starting this operation.

Important

After completion of the door reversal operation, verify that the door gasket is sealing onto the cabinet.
If the ambient temperature is cold (i.e. in Winter), the gasket may not fit perfectly to the cabinet. In that case, wait for the natural fitting of the gasket or accelerate this process by heating up the part involved with a normal hairdryer on a low setting.

ELECTRICAL CONNECTION

WARNING:

THIS APPLIANCE MUST BE EARTHED. The manufacturer declines any liability should this safety measure not be observed.

If the plug that is fitted to your appliance is not suitable for your socket outlet, it must be cut off and the appropriate plug fitted.

Remove the fuse from the cut off plug.
The cut off plug should then be disposed of to prevent the hazard of shocks in case it should be plugged into a 13amp socket in another part of your home.

Important

The wires in the mains lead are coloured in accordance with the following code:

Green and Yellow	**- Earth**
Blue	**- Neutral**
Brown	**- Live**

If you fit your own plug, the colours of the wires in the mains lead of your appliance, may not correspond with the markings identifying the terminals in your plug, proceed as follows:

Connect the Green and the Yellow (earth) wire to the terminal in the plug which is marked with the letter «E» or the earth symbol ⏚ , or coloured green and yellow.

Connect the blue (neutral) wire to the terminal in the plug which is marked with the letter «N» or coloured black.

Connect the brown (live) wire to the terminal in the plug which is marked with the letter «L» or coloured red.

The plug moulded onto the lead incorporates a fuse. For replacement, use a 13amp BS1362 fuse. Only ASTA or BSI approved fuses should be used.

The plug must not be used if the fuse cover/carrier is lost. The cover/carrier is indicated by the coloured insert at the base of the plug.
A replacement cover/carrier must be obtained from your local Service Force Centre.

This appliance complies with the E.E.C. Directive No. 87/308 of 2.6.87 relative to radio interference suppression.

CE This appliance complies with the following E.E.C. Directive:

- **73/23 EEC** of 19.2.73 (Low Voltage Directive) and subsequent amendments.
- **89/336 EEC** of 3.5.89 (Electromagnetic Compatibility Directive) and subsequent amendments.

Please ensure that when the appliance is installed it is easily accessible for the engineer in the event of breakdown.



From the Electrolux Group. *The world's No.1 choice.*

The Electrolux Group is the world's largest producer of powered appliances for kitchen, cleaning and outdoor use. More than 55 million Electrolux Group products (such as refrigerators, cookers, washing machines, vacuum cleaners, chain saws and lawn mowers) are sold each year to a value of approx. USD 14 billion in more than 150 countries around the world.

© Electrolux Household Appliances Limited 2001